



# ***939Dual-SATA2***

## **User Manual**

Version 1.1

Published July 2006

Copyright©2006 ASRock INC. All rights reserved.

---

### **Copyright Notice:**

No part of this manual may be reproduced, transcribed, transmitted, or translated in any language, in any form or by any means, except duplication of documentation by the purchaser for backup purpose, without written consent of ASRock Inc.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

### **Disclaimer:**

Specifications and information contained in this manual are furnished for informational use only and subject to change without notice, and should not be constructed as a commitment by ASRock. ASRock assumes no responsibility for any errors or omissions that may appear in this manual.

With respect to the contents of this manual, ASRock does not provide warranty of any kind, either expressed or implied, including but not limited to the implied warranties or conditions of merchantability or fitness for a particular purpose.

In no event shall ASRock, its directors, officers, employees, or agents be liable for any indirect, special, incidental, or consequential damages (including damages for loss of profits, loss of business, loss of data, interruption of business and the like), even if ASRock has been advised of the possibility of such damages arising from any defect or error in the manual or product.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**ASRock Website: <http://www.asrock.com>**

---

## Contents

<b>1. Introduction .....</b>	<b>5</b>
1.1 Package Contents .....	5
1.2 Specifications .....	6
1.3 Motherboard Layout .....	8
1.4 ASRock 8CH I/O .....	9
<b>2. Installation .....</b>	<b>10</b>
Pre-installation Precautions .....	10
2.1 CPU Installation .....	11
2.2 Installation of CPU Fan and Heatsink .....	11
2.3 Installation of Memory Modules (DIMM) .....	12
2.4 Expansion Slots (Future CPU Port, PCI Slots, PCIE Slots, and AGP Slot) .....	14
2.5 Jumpers Setup .....	16
2.6 Surround Display Feature .....	16
2.7 Onboard Headers and Connectors .....	17
2.8 Serial ATA (SATA) Hard Disks Installation .....	20
2.9 Making a SATA Driver Diskette For SATA Operation in .....	
"RAID" Mode. ....	20
2.10 SATA Operating in "non-RAID" Mode .....	21
2.11 SATAII Operating in "IDE" Mode .....	21
2.12 Making a SATAII Driver Diskette For SATAII Operation in .....	
"SATA" Mode. ....	21
<b>3. BIOS SETUP UTILITY .....</b>	<b>22</b>
3.1 Introduction .....	22
3.1.1 BIOS Menu Bar .....	22
3.1.2 Navigation Keys .....	23
3.2 Main Screen .....	23
3.3 Advanced Screen .....	24
3.3.1 CPU Configuration .....	25
3.3.2 Chipset Configuration .....	27
3.3.3 ACPI Configuration .....	28
3.3.4 IDE Configuration .....	29
3.3.5 PCIPnP Configuration .....	32
3.3.6 Floppy Configuration .....	33
3.3.7 Super IO Configuration .....	33
3.3.8 USB Configuration .....	35
3.4 Hardware Health Event Monitoring Screen .....	35
3.5 Boot Screen .....	36
3.5.1 Boot Settings Configuration .....	36



---

3.6	Security Screen .....	37
3.7	Exit Screen .....	38
<b>4.</b>	<b>Software Support .....</b>	<b>39</b>
4.1	Install Operating System .....	39
4.2	Support CD Information .....	39
4.2.1	Running Support CD .....	39
4.2.2	Drivers Menu .....	39
4.2.3	Utilities Menu .....	39
4.2.4	Contact Information .....	39
	<b>APPENDIX: AMD's Cool 'n' Quiet™ Technology.....</b>	<b>40</b>



---

## 1. Introduction

Thank you for purchasing ASRock **939Dual-SATA2** motherboard, a reliable motherboard produced under ASRock's consistently stringent quality control. It delivers excellent performance with robust design conforming to ASRock's commitment to quality and endurance.

In this manual, chapter 1 and 2 contain introduction of the motherboard and step-by-step guide to the hardware installation. Chapter 3 and 4 contain the configuration guide to BIOS setup and information of the Support CD.



Because the motherboard specifications and the BIOS software might be updated, the content of this manual will be subject to change without notice. In case any modifications of this manual occur, the updated version will be available on ASRock website without further notice. You may find the latest memory and CPU support lists on ASRock website as well. ASRock website <http://www.asrock.com>

### 1.1 Package Contents

- 1 x ASRock **939Dual-SATA2** Motherboard  
(ATX Form Factor: 12.0-in x 9.6-in, 30.5 cm x 24.4 cm)
- 1 x ASRock **939Dual-SATA2** Quick Installation Guide
- 1 x ASRock **939Dual-SATA2** Support CD
- 1 x Ultra ATA 66/100/133 IDE Ribbon Cable (80-conductor)
- 1 x 3.5-in Floppy Drive Ribbon Cable
- 1 x Serial ATA (SATA) Data Cable (Optional)
- 1 x Serial ATA (SATA) HDD Power Cable (Optional)
- 1 x ASRock 8CH I/O Shield

---

## 1.2 Specifications

<b>Platform:</b>	ATX Form Factor: 12.0-in x 9.6-in, 30.5 cm x 24.4 cm
<b>CPU:</b>	939-Pin Socket Supporting AMD Athlon™ 64 / 64FX Processor Supports AMD's Cool 'n' Quiet™ Technology (see <b>CAUTION 1</b> )
<b>Chipsets:</b>	North Bridge: ULi® M1695 chipset For 939-Pin CPU, FSB @ 1 GHz / 2.0 GT/s South Bridge: ULi® M1567 chipset, supports SATA 1.5Gb/s
<b>Memory:</b>	4 x DDR DIMM Slots: 4 DIMMs support PC3200 (DDR 400) / PC2700 (DDR 333) / PC2100 (DDR 266), Max. 4GB Dual Channel Memory Technology support (see <b>CAUTION 2</b> )
<b>IDE:</b>	IDE1: ATA 133 / Ultra DMA Mode 6 IDE2: ATA 133 / Ultra DMA Mode 6 Supports up to 4 IDE Devices
<b>Serial ATA:</b>	Supports up to 2 SATA devices at 1.5Gb/s data transfer rate (No support for "Hot Plug" functions)
<b>Serial ATA II:</b>	1 SATA II device at 3.0Gb/s data transfer rate (No support for "Hot Plug" functions)
<b>Floppy Port:</b>	Supports up to 2 Floppy Disk Drives
<b>Audio:</b>	7.1 channels AC'97 Audio
<b>LAN:</b>	Speed: 802.3u (10/100 Ethernet), Supports Wake-On-LAN
<b>Hardware Monitor:</b>	CPU Temperature Sensing Motherboard Temperature Sensing CPU Overheat Shutdown to Protect CPU Life (ASRock U-COP)(see <b>CAUTION 3</b> ) CPU Fan Tachometer Chassis Fan Tachometer Voltage Monitoring: +12V, +5V, +3.3V, Vcore
<b>Future CPU Port:</b>	Supports CPU upgrade from AMD 939-Pin CPU to other future CPU, such as 940-Pin CPU (M2) (see <b>page 14</b> for details)
<b>PCI Slots:</b>	3 x PCI Slots, PCI Specification 2.2
<b>PCI EXPRESS Slots:</b>	1 slot with PCIE x 16, 1 slot with PCIE x 1; PCIE Specification 1.0a
<b>AGP Slot:</b>	1 x AGP Slot Supports 1.5V, 8X / 4X AGP Card (see <b>CAUTION 4</b> )
<b>USB 2.0:</b>	8 USB 2.0 Ports: 4 Ready-to-Use USB 2.0 Ports on the I/O Panel Plus 2 On-Board Headers Supporting 4 Extra USB 2.0 Ports (see <b>CAUTION 5</b> )


---

<b>ASRock 8CH I/O:</b>	1 PS/2 Mouse Port, 1 PS/2 Keyboard Port 1 Serial Port: COM1 1 Parallel Port (ECP/EPP Support) 4 Ready-to-Use USB 2.0 Ports 1 RJ-45 Port Audio Jack: Side Speaker / Rear Speaker / Central/Bass / Line In / Front Speaker / Microphone (see <b>CAUTION 6</b> )
<b>BIOS:</b>	AMI Legal BIOS Supports "Plug and Play" ACPI 1.1 Compliance Wake Up Events SMBIOS 2.3.1 Support CPU Frequency Stepless Control (only for advanced users' reference, see <b>CAUTION 7</b> )
<b>OS:</b>	Microsoft® Windows® 2000 / XP / XP 64-bit compliant

### **CAUTION!**


1. For power-saving's sake, it is strongly recommended to enable AMD's Cool 'n' Quiet™ technology under Windows system. See APPENDIX on page 40 to enable AMD's Cool 'n' Quiet™ technology.
2. This motherboard supports Dual Channel Memory Technology. Before you implement Dual Channel Memory Technology, make sure to read the installation guide of memory modules on page 12 for proper installation.
3. While CPU overheat is detected, the system will automatically shutdown. Before you resume the system, please check if the CPU fan on the motherboard functions properly and unplug the power cord, then plug it back again. To improve heat dissipation, remember to spray thermal grease between the CPU and the heatsink when you install the PC system.
4. Do NOT use a 3.3V AGP card on the AGP slot of this motherboard!  
It may cause permanent damage!
5. Power Management for USB 2.0 works fine under Microsoft® Windows® XP SP1 / 2000 SP4.
6. For microphone input, this motherboard supports both stereo and mono modes. For audio output, this motherboard supports 2-channel, 4-channel, 6-channel, and 8-channel modes. Please check the table on page 9 for proper connection.
7. Although this motherboard offers stepless control, it is not recommended to perform over-clocking. Frequencies other than the recommended CPU bus frequencies may cause the instability of the system or damage the CPU.

### 1.3 Motherboard Layout



- |    |                                                                   |    |                                       |
|----|-------------------------------------------------------------------|----|---------------------------------------|
| 1  | PS2_USB_PWR1 Jumper                                               | 19 | Chassis Fan Connector (CHA_FAN1)      |
| 2  | ATX Power Connector (ATXPWR1)                                     | 20 | Clear CMOS Jumper (CLRRTC1)           |
| 3  | CPU Fan Connector (CPU_FAN1)                                      | 21 | USB 2.0 Header (USB67, Blue)          |
| 4  | ATX 12V Power Connector (ATX12V1)                                 | 22 | USB 2.0 Header (USB45, Blue)          |
| 5  | CPU Heatsink Retention Module                                     | 23 | Flash Memory                          |
| 6  | 939-Pin CPU Socket                                                | 24 | Floppy Connector (FLOPPY1)            |
| 7  | 2 x 184-pin DDR DIMM Slots<br>(Dual Channel A: DDR1, DDR2; Blue)  | 25 | Infrared Module Header (IR1)          |
| 8  | 2 x 184-pin DDR DIMM Slots<br>(Dual Channel B: DDR3, DDR4; Black) | 26 | Game Port Header (GAME1)              |
| 9  | North Bridge Controller                                           | 27 | Front Panel Audio Header (AUDIO1)     |
| 10 | Serial ATAII Connector (SATAII_1, red)                            | 28 | JR1 JL1 Jumper                        |
| 11 | JMicron JMB360 Chipset (PCIEX1 interface)                         | 29 | PCI Slots (PCI1- 3)                   |
| 12 | South Bridge Controller                                           | 30 | AGP Slot (1.5V_AGP1)                  |
| 13 | Secondary Serial ATA Connector (SATA2)                            | 31 | J9/J10 Jumper                         |
| 14 | Primary Serial ATA Connector (SATA1)                              | 32 | PCI EXPRESS Slot (PCIE2)              |
| 15 | Primary IDE Connector (IDE1, Blue)                                | 33 | J11 Jumper                            |
| 16 | Secondary IDE Connector (IDE2, Black)                             | 34 | PCI EXPRESS Slot (PCIE1)              |
| 17 | System Panel Header (PANEL1)                                      | 35 | Future CPU Port (FUTURE_CPU_PORT1)    |
| 18 | Chassis Speaker Header (SPEAKER 1)                                | 36 | Internal Audio Connector: CD1 (Black) |
|    |                                                                   | 37 | J1-J8 Jumpers                         |

## 1.4 ASRock 8CH I/O



- |                           |                                |
|---------------------------|--------------------------------|
| 1 Parallel Port           | 8 Microphone (Pink)            |
| 2 RJ-45 Port              | 9 USB 2.0 Ports (USB01)        |
| 3 Side Speaker (Gray)     | 10 USB 2.0 Ports (USB23)       |
| 4 Rear Speaker (Black)    | 11 Serial Port: COM1           |
| 5 Central / Bass (Orange) | 12 PS/2 Keyboard Port (Purple) |
| 6 Line In (Light Blue)    | 13 PS/2 Mouse Port (Green)     |
| *7 Front Speaker (Lime)   |                                |

\* If you use 2-channel speaker, please connect the speaker's plug into "Front Speaker Jack". See the table below for connection details in accordance with the type of speaker you use.

**TABLE for Audio Output Connection**

Audio Output Channels	Front Speaker (No. 7)	Rear Speaker (No. 4)	Central / Bass (No. 5)	Side Speaker (No. 3)
2	V	--	--	--
4	V	V	--	--
6	V	V	V	--
8	V	V	V	V

---

## 2. Installation

**939Dual-SATA2** is an ATX form factor (12.0-in x 9.6-in, 30.5 cm x 24.4 cm) motherboard. Before you install the motherboard, study the configuration of your chassis to ensure that the motherboard fits into it.

### Pre-installation Precautions

Take note of the following precautions before you install motherboard components or change any motherboard settings.



Before you install or remove any component, ensure that the power is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, and/or components.

1. Unplug the power cord from the wall socket before touching any component.
2. To avoid damaging the motherboard components due to static electricity, **NEVER** place your motherboard directly on the carpet or the like. Also remember to use a grounded wrist strap or touch a safety grounded object before you handle components.
3. Hold components by the edges and do not touch the ICs.
4. Whenever you uninstall any component, place it on a grounded anti-static pad or in the bag that comes with the component.
5. When placing screws into the screw holes to secure the motherboard to the chassis, please do not over-tighten the screws! Doing so may damage the motherboard.

---


## 2.1 CPU Installation

- Step 1. Unlock the socket by lifting the lever up to a 90° angle.
- Step 2. Position the CPU directly above the socket such that the CPU corner with the golden triangle matches the socket corner with a small triangle.
- Step 3. Carefully insert the CPU into the socket until it fits in place.



The CPU fits only in one correct orientation. DO NOT force the CPU into the socket to avoid bending of the pins.

- Step 4. When the CPU is in place, press it firmly on the socket while you push down the socket lever to secure the CPU. The lever clicks on the side tab to indicate that it is locked.



**STEP 1:**  
Lift Up The Socket Lever

**STEP 2 / STEP 3:**  
Match The CPU Golden Triangle  
To The Socket Corner

**STEP 4:**  
Push Down And Lock  
The Socket Lever

## 2.2 Installation of CPU Fan and Heatsink

After you install the CPU into this motherboard, it is necessary to install a larger heatsink and cooling fan to dissipate heat. You also need to spray thermal grease between the CPU and the heatsink to improve heat dissipation. Make sure that the CPU and the heatsink are securely fastened and in good contact with each other. Then connect the CPU fan to the CPU FAN connector (CPU\_FAN1, see Page 8, No. 3). For proper installation, please kindly refer to the instruction manuals of the CPU fan and the heatsink.

## 2.3 Installation of Memory Modules (DIMM)

**939Dual-SATA2** motherboard provides four 184-pin DDR (Double Data Rate) DIMM slots, and supports Dual Channel Memory Technology. For dual channel configuration, you always need to install **identical** (the same brand, speed, size and chip-type) DDR DIMM pair in the slots of the same color. In other words, you have to install **identical** DDR DIMM pair in **Dual Channel A** (DDR1 and DDR2; Blue slots; see p.8 No.7) or **identical** DDR DIMM pair in **Dual Channel B** (DDR3 and DDR4; Black slots; see p.8 No.8), so that Dual Channel Memory Technology can be activated. This motherboard also allows you to install four DDR DIMMs for dual channel configuration, and please install **identical** DDR DIMMs in all four slots. You may refer to the Dual Channel Memory Configuration Table below.

**Dual Channel Memory Configurations**

	DDR1 (Blue Slot)	DDR2 (Blue Slot)	DDR3 (Black Slot)	DDR4 (Black Slot)
(1)	Populated	Populated	-	-
(2)	-	-	Populated	Populated
(3)*	Populated	Populated	Populated	Populated

\* For the configuration (3), please install **identical** DDR DIMMs in all four slots.



1. If you want to install two memory modules, for optimal compatibility and reliability, it is recommended to install them in the slots of the same color. In other words, install them either in the set of blue slots (DDR1 and DDR2), or in the set of black slots (DDR3 and DDR4).
2. If only one memory module or three memory modules are installed in the DDR DIMM slots on this motherboard, it is unable to activate the Dual Channel Memory Technology.
3. If a pair of memory modules is NOT installed in the same Dual Channel, for example, installing a pair of memory modules in DDR1 and DDR3, it is unable to activate the Dual Channel Memory Technology .



---

## Installing a DIMM



Please make sure to disconnect power supply before adding or removing DIMMs or the system components.

- Step 1. Unlock a DIMM slot by pressing the retaining clips outward.  
Step 2. Align a DIMM on the slot such that the notch on the DIMM matches the break on the slot.



The DIMM only fits in one correct orientation. It will cause permanent damage to the motherboard and the DIMM if you force the DIMM into the slot at incorrect orientation.

- Step 3. Firmly insert the DIMM into the slot until the retaining clips at both ends fully snap back in place and the DIMM is properly seated.

## 2.4 Expansion Slots

### (Future CPU Port, PCI Slots, PCIe Slots, and AGP Slot)

There are 1 Future CPU Port, 3 PCI slots, 2 PCIe slots, and 1 AGP slot on **939Dual-SATA2** motherboard.

#### Future CPU Port (Yellow-Colored Port):

Future CPU Port allows you to upgrade your AMD 939-Pin CPU to AMD 940-Pin CPU by installing an add-on ASRock **M2CPU Board** into this future CPU Port on **939Dual-SATA2** motherboard. Before you upgrade the 939-Pin CPU to the 940-Pin (M2) CPU, it is necessary to adjust the jumper settings for those required jumpers on **939Dual-SATA2** motherboard. Please refer to the table below for the correct jumper settings.



This yellow-colored Future CPU Port is not an AGP slot! Please do NOT insert any AGP card into it!

CPU Type	Jumper Settings
939-Pin CPU (Default)	
940-Pin (M2) CPU (Using add-on ASRock <b>M2CPU            Board</b> )	

---

## NOTE

When adjusting the jumper settings, you may use the tool, Jumper Cap Remover, to help you removing the jumper caps more easily. This Jumper Cap Remover is bundled in your motherboard package, and please follow the "Jumper Cap Remover Instruction" to use it properly.

**PCI Slots:** PCI slots are used to install expansion cards that have the 32-bit PCI interface.

**PCIe Slots:** PCIe1 (PCIe x 16 slot) is used for PCI Express cards with x16 lane width graphics cards.

PCIe2 (PCIe x 1 slot) is used for PCI Express cards, such as Gigabit LAN card, SATA2 card, etc.

**AGP slot:** The AGP slot is used to install a graphics card. The ASRock AGP slot has a special design of clasp that can securely fasten the inserted graphics card.



Please do NOT use a 3.3V AGP card on the AGP slot of this motherboard! It may cause permanent damage! For the voltage information of your AGP card, please check with the AGP card vendors.

## Installing an expansion card


- Step 1. Before installing the expansion card, please make sure that the power supply is switched off or the power cord is unplugged. Please read the documentation of the expansion card and make necessary hardware settings for the card before you start the installation.
- Step 2. Remove the system unit cover (if your motherboard is already installed in a chassis).
- Step 3. Remove the bracket facing the slot that you intend to use. Keep the screws for later use.
- Step 4. Align the card connector with the slot and press firmly until the card is completely seated on the slot.
- Step 5. Fasten the card to the chassis with screws.
- Step 6. Replace the system cover.



## 2.5 Surround Display Feature

This motherboard supports Surround Display upgrade. With the external add-on PCI VGA card and PCI Express VGA card, you can easily enjoy the benefits of Surround Display feature. For the detailed instruction, please refer to the document at the following path in the Support CD: ..\ Surround Display

## 2.6 Jumpers Setup

The illustration shows how jumpers are setup. When the jumper cap is placed on pins, the jumper is "Short". If no jumper cap is placed on pins, the jumper is "Open". The illustration shows a 3-pin jumper whose pin1 and pin2 are "Short" when jumper cap is placed on these 2 pins.



Jumper	Setting	
PS2_USB_PWR1 (see p.8, No. 1)	 	Short pin2, pin3 to enable +5VSB (standby) for PS/2 or USB wake up events.

Note: To select +5VSB, it requires 2 Amp and higher standby current provided by power supply.

JR1 JL1 Jumper (see p.8, No. 28)	
-------------------------------------	-------------------------------------------------------------------------------------

Note: If the jumpers JL1 and JR1 are short, both the front panel and the rear panel audio connectors can work.

Clear CMOS Jumper (CLRTC1) (see p.8, No. 20)	 
----------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Note: CLRTC1 allows you to clear the data in CMOS. The data in CMOS includes system setup information such as system password, date, time, and system setup parameters. To clear and reset the system parameters to default setup, please turn off the computer and unplug the power cord from the power supply. After waiting for 15 seconds, use a jumper cap to short pin2 and pin3 on CLRTC1 for 5 seconds. However, please do not clear the CMOS right after you update the BIOS. If you need to clear the CMOS when you just finish updating the BIOS, you must boot up the system first, and then shut it down before you do the clear-CMOS action.

## 2.7 Onboard Headers and Connectors



Onboard headers and connectors are NOT jumpers. Do NOT place jumper caps over these headers and connectors. Placing jumper caps over the headers and connectors will cause permanent damage of the motherboard!

### Floppy Connector

(33-pin FLOPPY1)

(see p.8 No. 24)



the red-striped side to Pin1

Note: Make sure the red-striped side of the cable is plugged into Pin1 side of the connector.

### Primary IDE Connector (Blue)

(39-pin IDE1, see p.8 No. 15)



### Secondary IDE Connector (Black)

(39-pin IDE2, see p.8 No. 16)



connect the blue end  
to the motherboard



connect the black end  
to the IDE devices

80-conductor ATA 66/100/133 cable

Note: If you use only one IDE device on this motherboard, please set the IDE device as "Master". Please refer to the instruction of your IDE device vendor for the details. Besides, to optimize compatibility and performance, please connect your hard disk drive to the primary IDE connector (IDE1, blue) and CD-ROM to the secondary IDE connector (IDE2, black).

### Serial ATA Connectors

(SATA1: see p.8 No. 14)

(SATA2: see p.8 No. 13)



These two Serial ATA (SATA) connectors support SATA data cables for internal storage devices. The current SATA interface allows up to 1.5 Gb/s data transfer rate.

### Serial ATA II Connector

(SATAII\_1: see p.8 No. 10)



This Serial ATA II (SATA II) connector supports SATA II data cables for internal storage devices. The current SATA II interface allows up to 3.0 Gb/s data transfer rate.




It is recommended to plug SATAII HDD to SATAII connector (SATAII\_1) and connect SATA HDD to SATA connector (SATA1 or SATA2).

### Serial ATA (SATA) Data Cable




Either end of the SATA data cable can be connected to the SATA hard disk or the SATA connector on the motherboard.

**Serial ATA (SATA)  
Power Cable**  
(Optional)




Please connect the black end of SATA power cable to the power connector on each drive. Then connect the white end of SATA power cable to the power connector of the power supply.

**USB 2.0 Header**  
(9-pin USB67)  
(see p.8 No. 21)




ASRock 8CH I/O accommodates 4 default USB 2.0 ports. If those USB 2.0 ports on the I/O panel are not sufficient, this USB 2.0 header is available to support 2 additional USB 2.0 ports.

**USB 2.0 Header**  
(9-pin USB45)  
(see p.8 No. 22)




ASRock 8CH I/O accommodates 4 default USB 2.0 ports. If those USB 2.0 ports on the I/O panel are not sufficient, this USB 2.0 header is available to support 2 additional USB 2.0 ports.

**Infrared Module Header**  
(5-pin IR1)  
(see p.8 No. 25)




This header supports an optional wireless transmitting and receiving infrared module.

**Internal Audio Connectors**  
(4-pin CD1)  
(CD1: see p.8 No. 36)



This connector allows you to receive stereo audio input from sound sources such as a CD-ROM, DVD-ROM, TV tuner card, or MPEG card.

**Front Panel Audio Header**  
(9-pin AUDIO1)  
(see p.8 No. 27)




This is an interface for front panel audio cable that allows convenient connection and control of audio devices.

---

### System Panel Header

(9-pin PANEL1)  
(see p.8 No. 17)




This header accommodates several system front panel functions.

---

### Chassis Speaker Header

(4-pin SPEAKER 1)  
(see p.8 No. 18)




Please connect the chassis speaker to this header.

---

### Chassis Fan Connector

(3-pin CHA\_FAN1)  
(see p.8 No. 19)




Please connect a chassis fan cable to this connector and match the black wire to the ground pin.

---

### CPU Fan Connector

(3-pin CPU\_FAN1)  
(see p.8 No. 3)



Please connect the CPU fan cable to this connector and match the black wire to the ground pin.

---

### ATX Power Connector

(20-pin ATXPWR1)  
(see p.8 No. 2)



Please connect an ATX power supply to this connector.

---

### ATX 12V Power Connector

(4-pin ATX12V1)  
(see p.8 No. 4)




Please note that it is necessary to connect a power supply with ATX 12V plug to this connector. Failing to do so will cause power up failure.

---

### Game Port Header

(15-pin GAME1)  
(see p.8 No. 26)



Connect a Game cable to this header if the Game port bracket is installed.

---

## 2.8 Serial ATA (SATA) Hard Disks Installation

This motherboard adopts JMicron JMB360 chipset that supports Serial ATAII (SATAII) hard disk. It also adopts ULI M1567 south bridge chipset that supports Serial ATA (SATA) hard disks, and supports RAID functions. You may install SATA hard disks on this motherboard for internal storage devices. This section will guide you to install the SATA hard disks.

- STEP 1: Install the SATA hard disks into the drive bays of your chassis.
- STEP 2: Connect the SATA power cable to the SATA hard disk.
- STEP 3: Connect one end of the SATA data cable to the motherboard's SATA connector.
- STEP 4: Connect the other end of the SATA data cable to the SATA hard disk.



1. If you plan to use RAID 0, RAID 1, or JBOD functions on SATA, SATA HDDs must be operated in "RAID" mode.
2. "RAID" and "non-RAID" mode are options under "SATA Operation Mode" in BIOS setup. Please refer to page 30 for details. They need different drivers during actual operation.

## 2.9 Making a SATA Driver Diskette For SATA Operation in "RAID" Mode

If you want to install Windows 2000, Windows XP, or Windows XP 64-bit OS on your SATA HDDs, you will need to make a SATA driver diskette before you start the OS installation.

- STEP 1: Insert the ASRock Support CD into your optical drive to boot your system. (Do NOT insert any floppy diskette into the floppy drive at this moment!)
- STEP 2: During POST at the beginning of system boot-up, press <F11> key, and then a window for boot devices selection appears. Please select CD-ROM as the boot device.
- STEP 3: When you see the message on the screen, "Do you want to generate Serial ATA driver diskette [YN]?", press <Y>.
- STEP 4: Then you will see these messages,  
**Please insert a diskette into the floppy drive.**  
**WARNING! Formatting the floppy diskette will lose ALL data in it!**  
**Start to format and copy files [YN]?**  
Please insert a floppy diskette into the floppy drive, and press <Y>.
- STEP 5: The system will start to format the floppy diskette and copy SATA drivers into the floppy diskette.

---

Once you have the SATA driver diskette ready, you may start to install Windows 2000 / Windows XP / Windows XP 64-bit on your system directly without setting the RAID configuration on your system, or you may start to use "RAID Installation Guide" to set RAID 0 / RAID 1 / JBOD configuration before you install the OS. Before you start to configure the RAID function, you need to check the installation guide in the Support CD for proper configuration. Please find the document, "Guide to SATA Hard Disks Installation and RAID Configuration", at the following path in the Support CD:

`..\ Information \ Manual \ RAID Installation Guide \ English.pdf`

## **2.10 SATA Operating in "non-RAID" Mode**

If you want to install Windows 2000, Windows XP, or Windows XP 64-bit OS on your SATA HDDs operating in non-RAID mode, you don't need to make a SATA driver diskette before OS installation.

## **2.11 SATAII Operating in "IDE" Mode**

If you want to install Windows 2000, Windows XP, or Windows XP 64-bit OS on your SATAII HDDs operating in IDE mode, you don't need to make a SATAII driver diskette before OS installation.

## **2.12 Making a SATAII Driver Diskette For SATAII Operation in "SATA" Mode**

If you want to install Windows 2000, Windows XP, or Windows XP 64-bit OS on your SATAII HDDs, you will need to make a SATAII driver diskette before you start the OS installation. You need to copy the SATAII driver package to a diskette and use it while OS queries for other boot device driver diskette. (Please see the "Readme.txt" in SATAII driver directory on the support CD for the files needed to copy to the diskette.)

---

## 3. BIOS SETUP UTILITY

### 3.1 Introduction

This section explains how to use the BIOS SETUP UTILITY to configure your system. The Flash Memory on the motherboard stores the BIOS SETUP UTILITY. You may run the BIOS SETUP UTILITY when you start up the computer. Please press <F2> during the Power-On-Self-Test (POST) to enter the BIOS SETUP UTILITY, otherwise, POST will continue with its test routines.

If you wish to enter the BIOS SETUP UTILITY after POST, restart the system by pressing <Ctl> + <Alt> + <Delete>, or by pressing the reset button on the system chassis. You may also restart by turning the system off and then back on.



Because the BIOS software is constantly being updated, the following BIOS setup screens and descriptions are for reference purpose only, and they may not exactly match what you see on your screen.

#### 3.1.1 BIOS Menu Bar

The top of the screen has a menu bar with the following selections:

- Main** To set up the system time/date information
- Advanced** To set up the advanced BIOS features
- H/W Monitor** To display current hardware status
- Boot** To set up the default system device to locate and load the Operating System
- Security** To set up the security features
- Exit** To exit the current screen or the BIOS SETUP UTILITY

Use <←> key or <→> key to choose among the selections on the menu bar, and then press <Enter> to get into the sub screen.


### 3.1.2 Navigation Keys

Please check the following table for the function description of each navigation key.

Navigation Key(s)	Function Description
← / →	Moves cursor left or right to select Screens
↑ / ↓	Moves cursor up or down to select items
+ / -	To change option for the selected items
<Enter>	To bring up the selected screen
<F1>	To display the General Help Screen
<F9>	To load optimal default values for all the settings
<F10>	To save changes and exit the BIOS SETUP UTILITY
<ESC>	To jump to the Exit Screen or exit the current screen

### 3.2 Main Screen

When you enter the BIOS SETUP UTILITY, the Main screen will appear and display the system overview.



#### System Time [Hour:Minute:Second]

Use this item to specify the system time.


#### System Date [Day Month/Date/Year]

Use this item to specify the system date.

In the future, you may upgrade your AMD 939-Pin CPU to AMD 940-Pin (M2) CPU by installing an add-on ASRock **M2CPU Board** into future CPU Port on this motherboard


### 3.3 Advanced Screen

In this section, you may set the configurations for the following items: CPU Configuration, Chipset Configuration, ACPI Configuration, IDE Configuration, PCI/PnP Configuration, Floppy Configuration, SuperIO Configuration, and USB Configuration.



Setting wrong values in this section may cause the system to malfunction.

### 3.3.1 CPU Configuration



#### Overclock Mode

Use this to select Overclock Mode. The default value is [Auto]. Configuration options: [Auto], [CPU, PCIE, Sync.] and [CPU, PCIE, Async.].

#### CPU Frequency (MHz)

Use this option to adjust CPU frequency. The range is from 140MHz to 300MHz. The default value is [200].

#### PCIE Frequency (MHz)

Use this option to adjust PCIE frequency. The range is from 70MHz to 150MHz. The default value is [100].

#### Boot Failure Guard

Enable or disable the feature of Boot Failure Guard.

#### Spread Spectrum

This feature will be set to [Auto] as default.

#### Cool 'n' Quiet

Use this item to enable or disable AMD's Cool 'n' Quiet™ technology.

#### Processor Maximum Multiplier


It will display Processor Maximum Multiplier for reference.

#### Processor Maximum Voltage

It will display Processor Maximum Voltage for reference.

#### Multiplier/Voltage Change

This item is set to [Auto] by default. If it is set to [Manual], you may adjust the value of Processor Multiplier and Processor Voltage. However, it is recommended to keep the default value for system stability.



### Processor Multiplier

This item will show when "Multiplier/Voltage Change" is set to [Manual]; otherwise, it will be hidden. You may set the value from [x8 1600 MHz] up to [x25 5000 MHz] but no higher than the value of "Processor Maximum Multiplier". For example, if the value of "Processor Maximum Multiplier" is [x11 2200 MHz], the actual value of multiplier will be [x11 2200 MHz] even if you set this item to a value higher than [x11 2200 MHz]. However, for system stability, it is not recommended to adjust the value of this item.

### Processor Voltage

This item will show when "Multiplier/Voltage Change" is set to [Manual]; otherwise, it will be hidden. For safety and system stability, it is not recommended to adjust the value of this item.

### Memory Clock

This item can be set by the code using [Auto]. You can set one of the standard values as listed: [133 MHz (DDR266)], [166 MHz (DDR333)], [200 MHz (DDR400)].

### Flexibility Option

The default value of this option is [Disabled]. It will allow better tolerance for memory compatibility when it is set to [Enabled].

### Burst Length

Burst length can be set to 8 or 4 beats. 64 Bit Dq must use the 4 beats.

### CAS Latency (CL)

Use this item to adjust the means of memory accessing. Configuration options: [Auto], [2.0], [3.0], and [2.5].



























